



## Joints, screwthread fittings, caps, rings & washers



- For use with Quickfit<sup>®</sup> glass screwthreads
- Melamine screwcaps with aperture at the top
- Silicone rubber rings with PTFE washers
- To determine what components are required:

i) Check the size of the glass screwthread (size designation refers to O.D. of thread in mm)

ii) Check the O.D. of the sampling tube, thermometer, probe etc that is to be passed through the screwcap

iii) Consult the table below: order relevant cap, washer and ring separately

## Plastic caps


Item Code	Thread size	Acceptable dia. through screwcap mm	Pack qty.
QC13/7	13	6.0 - 7.0	10
QC18/11	18	7.0 - 8.5	10
QC24/12	24	6.0 - 7.0	10
QC28/9	28	6.0 - 7.0	10
QC28/13	28	10.5 - 11.5	10
QC28/21	28	18.0 - 19.0	10

## Rubber rings

Thread size	Acceptable dia. through screwcap mm	Pack qty.
13	6.0-7.0	10
18	7.0-8.5	10
24	6.0-7.0	10
24	8.5-9.5	10
24	10.5-11.5	10
28	6.0-7.0	10
28	10.5-11.5	10
28	18.0-19.0	10
	13 18 24 24 24 24 24 28 28 28	Thread size through screwcap mm   13 6.0-7.0   18 7.0-8.5   24 6.0-7.0   24 8.5-9.5   24 10.5-11.5   28 6.0-7.0

## **PTFE** washers

Item Code	Thread size	Acceptable dia. through screwcap mm	Pack qty.
QW13/6	13	6.0-7.0	10
QW18/7	18	7.0-8.5	10
QW24/6	24	6.0-7.0	10
QW24/9	24	8.5-9.5	10
QW24/11	24	10.5-11.5	10
QW28/6	28	6.0-7.0	10
QW28/11	28	10.5-11.5	10
QW28/18	28	18.0-19.0	10



QR:

QW:

SQ:

 $\square$ 

