## **3M Personal Safety**



# 3M<sup>™</sup> Aircare<sup>™</sup> Wall/Floor Mounted Filtration Unit ACU-01 / ACU-02 Care and Maintenance

To maintain protection levels, optimise the effective lifetime of the system and avoid the additional cost of replacement, it is extremely important to carry out regular checks and maintenance on equipment.

## Before Use

- Ensure red indicator is not showing
- Check all connections are airtight
- Verify filter bowls are secure and free from collected liquids

#### Monthly if not in regular use

- General Inspection
- Six Monthly
- Change Filter

## After Use

- Depressurise unit
- General Inspection
- Cleaning of Stage 1 Filter

#### After 500 Hours Use

- Replacement of Stage 1 Filter Element
- Replacement of Stage 2 Filter Element (unless otherwise indicated by differential pressure indicator)
- Replacement of Stage 3 Filter Element (or if odour is detected

#### Replacement of Seals (Can be replaced at same time as elements if required)

If the unit is used at a higher temperature (+50°C to +80°C), extra maintenance will be required (see table following), which should be carried out in addition to the usual maintenance schedule. The gauge must be checked, and re-set if necessary, after any exposure to the higher temperature range.

## 🔰 @3M UK Safety

**3M Personal Safety Division** 3M United Kingdom plc 3M Centre Cain Road, Bracknell Berkshire RG12 8HT Tel: 0870 60 800 60 www.3M.co.uk/Safety

**3M Ireland Limited** The Iveagh Building The Park Carrickmines Dublin 18 Tel: 1 800 320 500

	Replace seals (if not replaced regularly)	Replace unit
Infrequent exposure	2.5 years	5 years
8 hours exposure per day	12 months	2 years
Constant exposure	12 months	

#### Ordering Consumables, Repair Parts and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.

## Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M Powered and Supplied Air Equipment, please contact the Helpline or your local 3M representative.





Α

С











		3M Part No
	Aircare Filtration Unit - wall unit	ACU-01
	Aircare Filtration Unit - floor unit	ACU-02
Α	Replacement filter kit (set of 3)	ACU-10
В	Pressure gauge	ACU-14
C	CEJN `342' socket and plug	530-12-81P3
C	Rectus `25' socket and plug	530-12-82P3
	CAST connector	530-12-85P3
D	2-way manifold	312-03-01P
D	3-way manifold	312-03-00P3

The 3M<sup>™</sup> Aircare<sup>™</sup> Filtration Unit provides high quality air from an external source of compressed air by removing water and oil droplets, solid particles and odours. The unit removes condensation and contamination from within the air system before it is delivered to the user.

## ିକ୍ camlab

## Distributed by Industrial Scientific Supplies, a division of Camlab Ltd

Camlab Ltd, Norman Way Industrial Estate, Over, Cambridge, CB24 5WE Telephone: +44 (0)1954 233145 Email: sales@camlab.co.uk www.industrialscientific.co.uk

17808

3M and Aircare are trademarks of 3M Company Please recycle. Printed in UK. © 3M 2014. All rights reserved.

## **REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE CORRECT LEVELS OF PROTECTION**

For more information on all our products, call 3M Personal Safety Division on 0870 60 800 60 (UK) and 1800 320 500 (Ireland) or visit www.3M.co.uk/safety





